

## **Geberit Clean Handy**



Example image

## **Application purposes**

 For deactivating various electronic Geberit products such as washbasin taps, WC flush actuators and urinal flush controls for sanitary cleaning • For converting the operating modes of Geberit sanitary flush units

## Characteristics

· Battery-operated

## Art. no.

115.831.00.1